CABINET PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10168325	Use & Care Guide
	W10281957	Service & Wiring Sheet
	W10353598	Energy Label
2	2150304	Front Roller
3	W10297485	Screw
4	12477102	Roller (Rear)
5	12477202	Axle, Roller
6	W10285005	Rivet, Roller
7	W10379525	Drain Tube Assy
8	W10257186	Bracket, Foot
9	W10141622	Foot, Brake
10	W10308750	Screw
11	W10238100	Valve, Inlet
12	W10249922	Hinge, Top (FC)
13	W10249925	Hinge, Top (RC)
14	W10308489	Screw
15	W10249943	Bottom Hinge (FC)
16	W10257209	Bottom Hinge (RC)
17	W10257197	Door Closer (RC)
18	W10141645	Screw
19	549193	Clamp, Service Cord
20	W10333887	Cover, Unit
21	12587703AP	Filler, Wrapper
22	W10257234	Grille
23	W10142234	Screw
24	W10257200	Door Closer (FC)
25	W10001250	Screw
26	W10277956	Tube, Filter Inlet
27	W10277957	Tube, Filter Outlet
28	W10370680	Drain Fitting
29	12957702	Cover
30	W10120821	Elec. Control−15W Power Supply
31	W10235414	Elec. Control
32		Cabinet (Not A Serviceable Part)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	W10260988	Escutcheon, Meat Pan Control
3	W10260989	Slide, Meat Pan Contro
4	W10322031	Air Diffuser Assembly
5	W10300475	Air Diffuser Cover
6	C3680314	Switch Rocker Arm
7	W10366790	Reservoir
8	W10279030	LED Light Assy
9	W10280385	Thermistor
10	W10295370	Water Filter
11	W10315189	Air Filter
12	W10364503	Air Filter Cover
13	W10238123	Housing, Water Filter
14	W10356630	Cover, Thermistor
15	W10271541	Connector, 1/4 x 5/16
16	W10300484	Cover, Water Filter

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)





Illus. No.	Part No.	DESCRIPTION
1	W10290870	Shelf, Snack Pan
2	W10278139	Roller
3	W10257334	Slide, Humidity
4	W10257332	Housing, Humidity
5	W10290876	Cover, Assy
6	W10256809	Snack Pan (Includes 2 & 8)
7	W10256812	Crisper Pan (Includes 2, 3, 4, & 8)
8	W10257246	Axle, Roller
9	W10256813	Meat Pan (Includes 2 & 8)
10	W10395554	Wine Rack
11	W10396209	Shelf Assy

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	W10290890	Cover Assy
3	W10393383	Shelf, Glass Upper
4	W10280386	Thermistor
5	W10393382	Shelf, Glass Lower
6	W10322533	Pan, Freezer Upper (Includes 7 & 14)
7	W10278139	Roller
8	2149954	Switch, Rocker Arm Upper
9	W10279030	LED Light Assy
10	1115373	Switch, Rocker Arm Lower
11	W10356632	Cover, Thermistor
12	W10322536	Pan, Freezer Lower (Includes 7 & 14)
13	W10294700	Lens, Light
14	W10257246	Axle, Roller

MOTOR AND ICE CONTAINER PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10353207	Ice Bin Assy
2	W10286610	Ice Bin
3	W10258552	Latch, Assy
4	2220458	Coupling, Lower
5	W10258544	Drive Shaft
6	2198607	Spring, Coupling
7	W10293211	Mounting Plate Assembly
8	2198628	Seal
9	W10291905	Gasket
10	2212370	Washer
11	2323603	Dispenser, Motor
12	W10287594	Cover, Container
100	W10353207	Ice Container (Complete)

REFRIGERATOR DOOR PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item 5)
	W10365610	Mono Stainless
2	W10010140	Set Screw
3	W10296816	Screw
4	W10335219	Door Bin, Gallon
5	W10249918	Door Gasket, Magnetic
6	W10274730	Handle
7	2200087	Thimble−Top
8	W10170540	Stud, Handle
9	W10257203	Door Closer, Upper Cam
10	W10296804	Screw
11		Bracket, Door Stop
	W10247909	Chrome
12	2220214	Nameplate
13	W10257218	Cover, Door Stop

FREEZER DOOR PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8 And Dispenser Front Parts)
	W10397059	Mono Stainless
2	W10274730	Handle
3	2200087	Thimble−Top
4	W10296804	Screw
5	W10170540	Stud, Handle
6	W10335217	Door Bin
7	W10296816	Screw
8	W10249919	Door Gasket, Magnetic
9	W10257206	Door Closer, Upper Cam
10		Bracket, Door Stop
	W10247907	Chrome
11	W10010140	Set Screw
12	W10257223	Cover, Door Stop
13	2198634	Pin
14	2198635	Spring
15	W10258502	Cover, Emitter
16	W10180607	P.C. Board, Emitter
17	W10258510	Cover, Receiver
18	W10296530	P.C. Board, Receiver
19	W10258520	Flipper
20	W10258540	Slide, Ice Make Shut Off
21	W10242369	Harness, Emitter & Receiver

DISPENSER FRONT PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	W10276209	Grate, Drip Tray
3	W10174827	Bracket, Ice Door
4	W10339578	Chute, Door
5	W10205978	Motor, Ice Door
6	W10353566	Ice Door Assembly (Includes Items 3, 5, 7, & 8)
7	W10346124	Support, Ice Door
8	4449745	Screw
9	W10254252	Trim Ring
10	W10279849	Water Tube
11	W10388236	Electronic Control Assy
12	W10370594	Pad, Ice & Water
13	W10276225	Drip Tray, Insert
14	2305235	Spigot

UNIT PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10277958	Connector
2	12825802	Fan, Blade
3	W10240365	Condenser Assembly
4	W10142255	Screw
5	W10204187	Clip
6	W10171469	Screw
7	W10277958	Connector, 1/4
8	W10303521	Sleeve
9	W10142294	Screw
10		Start Device Combination Relay & Overload
	W10197428	Production
	W10128791	Service
11	W10219381	Tube Suction
12	W10248621	Clip, Condenser(2)
13		Capacitor
	2264017	Production
	2264017	Service
14	2325479	Process Tube
15	2205813	Strap
16	W10239732	Evaporator, FC
17	2161324	Clamp
18	2188874	Fan, Motor
19	W10251469	Tray, Evaporator
20	W10223361	Heat Shield
21		Drier
	W10177049	Production
	2317845	Service
22	W10251467	Air Baffle
23	W10277704	Support Plate, Compressor
24	W10261232	Power Cord
25	W10284726	Unit Cover, Bottom
26	W10239728	Heater, Defrost
27	W10356137	LED Power Supply
28	W10200250	Compressor (Includes Items 10, 13, 21, & 29) (Also Order 876765 Tube Kit)
29		Grommet (4)
	10835903	Production
	10835901	Service
30	W10296661	Clip
31	W10209479	Harness, Wiring Water Valve/Diode

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

ICEMAKER PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10237915	Bracket, Valve
2	628379	Clip, Fuse
3	W10238092	Water Tube
4	489478	Screw
5	W10258562	Filter Valve Asm
6	489478	Screw
7	W10251088	Cover
8	W10141625	Screw (2)
9	W10251081	Mold & Heater Assembly (Also Order 542638
10	W10347036	Fill Tube Assy.
11	W10318644	Ejector
12	W10251078	Ice Striper
13	2194712	Support
14	2315522	Retainer, Thermostat
15	2321258	Thermostat (Also Order 542369 Cement Alumilastic)
16	W10001240	Screw
17	W10251080	Bracket, Mounting
18	W10242365	Harness, Wiring
19	626691	Module Assembly
20	489136	Screw
21		Motor (Not Serviced, Order #19)
100	W10251076	Complete Icemaker Assembly

AIR FLOW PARTS

For Models: GSC25C6EYY01
(Monochromatic Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10251462	Fan Scroll
2	W10260421	Retainer, Fan Motor
3	W10260388	Air Duct, Upper
4	W10260437	Bi−Metal, Defrost
5	W10251475	Air Duct Freezer
6	W10001260	Screw
7	2315549	Fan Motor
8	2169142	Fan Blade
9	W10240370	Gasket, Evaporator Cover
10	2176759	Fan Grommet (2)
11	W10274578	Clip, Mounting
12	W10242409	Harness, Fan Evaporator (Includes #4)
13	W10142292	Screw, Evap Cover
14	W10388269	Cover, Evaporator (Includes #9)
15	W10274578	Clip, Air Duct

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GSC25C6EYY01
(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION

PAINT, PRESSURIZED SPRAY (12 oz.)

✻350942	Primer, White
✻350939	Black
✻350930	White
✻4392901	Biscuit
✻8171357	Graphite

PAINT, TOUCH−UP (1/2oz.)

72017	White
72032	Black
4392899	Biscuit
80051	Graphite

✻**Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.

PAINT, BULK (1 qt.)

799344	White
4392900	Biscuit
8171358	Graphite

Miscellaneous

W10300794	Handle Installation Kit
212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
505587	Sealer, Mastic (1 Qt.)
503695	Cork, Sealer (1/4 Pound)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
833938	Kit, Terminal Connector

TORX SCREW WRENCH

1117510	Torx Key